




19-7009-323-02

RT5 SLIP-ON EXHAUST, CARBON FIBER

TRIUMPH STREET TRIPLE
2008-2012



PARTS INCLUDED

Ref.	Part Number	Description	Qty
1)	00-200-02591	Slip-on Midpipe Assembly	1
2)	00-200-02594	Carbon Fiber Muffler Assembly	1
3)	05-31-47608	Muffler Adapter Bracket	1
4)	07-41-40004	Swivel Spring	1
5)	01-510812525-SS	M8-1.25x25mm Button Head Bolt	1
6)	01-7808-SS	8mm Flat Washer	1
7)	01-7408125-27	M8-1.25 Hex Flange Nut	1

08-50-47612 REV. A

19-7009-323-02

RT5 SLIP-ON EXHAUST, CARBON FIBER

TRIUMPH STREET TRIPLE
2008-2012

TOOLS REQUIRED

Ref.	Description	Ref.	Description
1)	3/8" Drive Ratchet	5)	8mm Allen Socket
2)	3" & 6" Extension	6)	10mm Socket
3)	5mm Allen Socket	7)	12mm Socket
4)	6mm Allen Socket	8)	14mm Wrench

INSTALLATION INSTRUCTIONS

NOTE: Prior to working on anything, make sure the motorcycle is cool and place securely on a service lift or side stand.

- 1) Remove the two allen bolts securing the seat to the motorcycle. Remove the seat.
- 2) Remove the allen bolts securing the left & right side tail section body panels. Remove the body panels. (Fig. 1)
- 3) Loosen the clamp securing the stock right side muffler to the midpipe. Remove the two bolts securing the muffler to the sub frame. Remove the muffler from the motorcycle. (Fig. 2)
- 4) Repeat Step #3 for the left side stock muffler removal.
- 5) Remove the midpipe mounting bolt from the sub frame. (Fig. 2)
- 6) Loosen the lower clamp securing the midpipe to the headpipe outlet. (Fig. 3)

NOTE: You may want to enlist help from a friend for the Steps #7-12.

- 7) Remove the two bolts securing the front of the gas tank to the motorcycle frame.



19-7009-323-02

RT5 SLIP-ON EXHAUST, CARBON FIBER

TRIUMPH STREET TRIPLE
2008-2012

- 8) Rotate the gas tank upward and securely prop it up so the sub frame mounting bolts can be accessed. (Fig. 4)
- 9) With a second person supporting the sub frame assembly, remove the four bolts securing the sub frame to the main motorcycle frame.
- 10) Carefully lift up on the sub frame in order to create enough room to remove the stock midpipe from the motorcycle. Remove the midpipe from the motorcycle.

NOTE: Make sure the gasket at the headpipe outlet did not come off with the stock midpipe. It will be re-used when the Jardine midpipe is installed.

- 11) Feed the new Jardine midpipe through the swingarm, and fully insert it into the headpipe outlet.
- 12) Carefully lower, and reinstall the sub frame assembly to the motorcycle. Lower and secure the gas tank. Tighten all hardware to factory specification.
- 13) Position the midpipe mounting bracket against the mounting boss on the sub frame, and loosely secure using the original hardware. Do not fully tighten at this time.
- 14) Place the supplied Muffler Adapter Bracket against the right side of the sub frame. Secure the bracket to the sub frame using the original muffler mounting hardware. (Fig. 5) Do not fully tighten at this time.
- 15) Slide the new RT-5 Muffler onto the midpipe outlet until it is fully seated. Secure to the midpipe using the supplied swivel spring.



19-7009-323-02

RT5 SLIP-ON EXHAUST, CARBON FIBER

TRIUMPH STREET TRIPLE
2008-2012

16) Using the supplied M8-1.25x25mm Button Head Bolt, 8mm flat washer, and M8-1.25 Hex Flange Nut, secure the new muffler to the **INSIDE** of the muffler adapter bracket. (Fig. 5)

17) Position the exhaust system so that it is in the best possible orientation. Fully tighten the headpipe outlet clamp, the midpipe mounting bolt, muffler adapter bracket hardware, and muffler mounting bolt.

18) **Clean all fingerprints and grease from the new slip-on exhaust. Failure to do so can prematurely discolor the finish of your new exhaust system.**



19) Reinstall the left & right side tail section body panels. Reinstall the seat. (Fig. 6)

20) Start the motorcycle, check for any exhaust leaks, then stand back and admire how clean your bike looks & sounds!



Terms & Conditions

Returns: All requests for product returns must be made within 30 days from date of purchase. The return has to have a Return Material Authorization (RMA) number from Jardine and must include a copy of the original purchase invoice. Customer pays for the return freight and Jardine will exchange product or process a credit to your account. All returns must be in the original packaging to be eligible for any credit or exchange. Any return sent C.O.D. will not be accepted. Special order sales are final and may not be returned.

All warranty claims must be made through your point of purchase.

Limited Warranty: Jardine's warranty extends to the original purchaser only and a copy of the sales receipt must be provided. Keep your receipts. Jardine products are warranted against defective materials and workmanship for a period of 1 year from date of original customer purchase and to the original customer only. Proof of purchase is required. Any non-defective, unopened, unused, not installed item may be returned within seven working days of receipt and will be subject to a 15% restocking / repackaging fee. Bluing and / or discoloration of chrome exhaust systems / products are not covered. Contact the Jardine Customer Service Department directly at 216-265-8400 to obtain a Return Material Authorization (RMA) number prior to return of product. Authorized product will be repaired or returned at Jardine's discretion. Jardine is not responsible for any other expenses, including labor for removal of defective parts incurred by the customer under the terms of this warranty. Nor shall Jardine be responsible for any damages whether consequential, special, contingent or otherwise, or expenses or injury arising from the use of Jardine products. A detailed copy of Sale Terms, Conditions and Warranty information is available at request.

Jardine and Jardine Performance Products are registered trademarks of SuperTrapp Industries, Inc. and may not be used without consent from SuperTrapp Industries, Inc. SuperTrapp Industries, Inc. retains all marketing rights to its products and trademarks.

Jardine Performance Products is manufactured by SuperTrapp Industries, Inc. in Cleveland, OH. Our exhausts, highway bars, backrests, fender kits & accessories for V-Twin, Metric, Sport & Dirt applications are made in the U.S.A. Jardine has been manufacturing performance products since 1959.

E: Jardine@SuperTrapp.com

www.JardineProducts.com

TECH: (216) 265-8400