



**PARTS INCLUDED**

Ref.	Part Number	Description	Qty
1)	05-31-43410	Backrest Mounting Bracket, Right	1
2)	05-31-43411	Backrest Mounting Bracket, Left	1
3)	02-14-39178	Front Mounting Spacer, 1/8"	2
4)	02-14-39179	Rear Mounting Spacer, 3/8"	2
5)	01-510812545-SS	M8-1.25x45mm Socket Button Head Bolt	2
6)	01-510812550-SS	M8-1.25x50mm Socket Button Head Bolt	2

**TOOLS REQUIRED**

Ref.	Description	Ref.	Description
1)	3/8" Drive Ratchet	4)	12mm Socket
2)	5mm Allen Socket	5)	Torque Wrench
3)	6mm Allen Socket		

REV. A  
08-50-43751

33-3007-01

BACKREST MOUNTING KIT, STEEL

KAWASAKI VN2000 VULCAN  
2004-08

## INSTALLATION INSTRUCTIONS

- 1) Remove the two fender strut mounting bolts from the left side of the rear fender.
- 2) Position the left side backrest mounting bracket against the left side fender strut cover. With one supplied 1/8" mounting spacer (front) and one 3/8" mounting spacer (rear) positioned between the backrest bracket and the fender strut cover, secure the bracket to the motorcycle using one supplied M8-1.25x45mm socket button head bolt (front) and one supplied M8-1.25x50mm socket button head bolt (rear).  
**NOTE:** Do not fully tighten mounting hardware at this time.
- 3) Repeat steps 1 & 2 for the right side backrest mounting bracket.
- 4) Place your selected backrest (not included with backrest mounting kit) in between the two backrest mounting brackets. Secure the backrest to the mounting brackets using the hardware that was supplied with your backrest.
- 5) Tighten the four backrest mounting bolts to 21 lb-ft.
- 6) Tighten the backrest mounting bracket bolts to factory specifications.

### WARNING

Some backrests are shipped with the assembly bolts loose to allow easier installation on the motorcycle. You must check and fully tighten all backrest bolts prior to operating your motorcycle. Failure to do so may result in backrest failure, causing serious injury or death.

# **Jardine**

**PERFORMANCE PRODUCTS**

## **Terms & Conditions**

**Returns:** All requests for product returns must be made within 30 days from date of purchase. The return has to have a Return Material Authorization (RMA) number from Jardine and must include a copy of the original purchase invoice. Customer pays for the return freight and Jardine will exchange product or process a credit to your account. All returns must be in the original packaging to be eligible for any credit or exchange. Any return sent C.O.D. will not be accepted. Special order sales are final and may not be returned.

**All warranty claims must be made through your point of purchase.**

**Limited Warranty:** Jardine's warranty extends to the original purchaser only and a copy of the sales receipt must be provided. Keep your receipts. Jardine products are warranted against defective materials and workmanship for a period of 1 year from date of original customer purchase and to the original customer only. Proof of purchase is required. Any non-defective, unopened, unused, not installed item may be returned within seven working days of receipt and will be subject to a 15% restocking / repackaging fee. Bluing and / or discoloration of chrome exhaust systems / products are not covered. Contact the Jardine Customer Service Department directly at 216-265-8400 to obtain a Return Material Authorization (RMA) number prior to return of product. Authorized product will be repaired or returned at Jardine's discretion. Jardine is not responsible for any other expenses, including labor for removal of defective parts incurred by the customer under the terms of this warranty. Nor shall Jardine be responsible for any damages whether consequential, special, contingent or otherwise, or expenses or injury arising from the use of Jardine products. A detailed copy of Sale Terms, Conditions and Warranty information is available at request.

Jardine and Jardine Performance Products are registered trademarks of SuperTrapp Industries, Inc. and may not be used without consent from SuperTrapp Industries, Inc. SuperTrapp Industries, Inc. retains all marketing rights to its products and trademarks.

Jardine Performance Products is manufactured by SuperTrapp Industries, Inc. in Cleveland, OH. Our exhausts, highway bars, backrests, fender kits & accessories for V-Twin, Metric, Sport & Dirt applications are made in the U.S.A. Jardine has been manufacturing performance products since 1959.

E: [Jardine@SuperTrapp.com](mailto:Jardine@SuperTrapp.com)

[www.JardineProducts.com](http://www.JardineProducts.com)

TECH: (216) 265-8400