



## PARTS INCLUDED

Ref.	Part Number	Description	Qty
1)	04-24-42056	Supersport Fender Bracket	1
2)	04-18-37156	Tall Mounting Spacer	2
3)	04-18-39616	Short Mounting Spacer	2
4)	01-510610020-SS	M6-1.0x20mm Socket Button Head Bolt	2
5)	01-510610030-SS	M6-1.0x30mm Socket Button Head Bolt	2
6)	01-7806-27	6mm Flat Washer	4
7)	01-7006100-27	M6-1.0 Hex Nylock Nut	4
	46-0001	License Plate Bolt Light Kit (Optional, Availabale Separately)	

08-50-39620 REV. B

46-3002-03

**SUPERSPORT FENDER KIT**

**KAWASAKI ZX-10R  
2004-05**

**TOOLS REQUIRED**

Ref.	Description	Ref.	Description
1)	3/8" Drive Ratchet	5)	12mm Socket
2)	6" Extension	6)	10mm Wrench
3)	4mm Allen Socket	7)	Soldering Iron (optional)
4)	10mm Socket	8)	Wire Cutters (optional)

**INSTALLATION INSTRUCTIONS**

- 1) Remove the passenger seat.
- 2) Disconnect the license plate light wire and the two turn signal wires, inside the trunk space. Feed the wires through the hole in the tail section.
- 3) Remove the four bolts that secure the rear fender to the tail section. Remove the rear fender.
- 4) Place the supplied mounting spacers between the new Supersport Fender bracket and the tail section. The tall mounting spacer are used on the two front mounting holes and the short on the rear.
- 5) Using the the two supplied M6-1.0x30mm button head bolts, two 6mm flat washers, and two M6-1.0 hex nylock nuts, secure the front of the fender kit to the tail section. Using the remaining hardware secure the rear of teh fender kit to the tail section.
- 6) Remove the turn signals from the original rear fender assembly. Remove the rubber grommets.
- 7) Install the turn signal rubber grommets into the provided slots in the supersport fender bracket. Mount the turn signals to the bracket using the original hardware. Feed the wires through the hole in the bracket and the tail piece and reconnect the wires.
- 8) Mount the license plate to the Supersport Fender bracket. You can chose to use the license plate bracket or just mount the license plate to the fender bracket.
- 9) Reinstall the passenger seat. Turn on the motorcycle and make sure all lighting is working correctly.

**LICENSE PLATE BOLT LIGHT INSTALLATION (optional, available separately)**

- 1) Use the license plate bolt lights to mount your license plate to the Supersport Fender Bracket.
- 2) Locate the now unused license plate light wires inside the tail section.

46-3002-03

SUPERSPORT FENDER KIT

KAWASAKI ZX-10R  
2004-05

---

**LICENSE PLATE BOLT LIGHT INSTALLATION (optional, available separately)**

- 3) Cut and strip the two wires used to power the stock license plate light.
- 4) Attach both the red wires from the license plate light bolts to one of the stripped license plate light wires. Solder the connection and cover.
- 5) Attach both the black wires from the license plate light bolts to the second of the stripped license plate light wires. Solder the connection and cover.
- 6) Turn on the motorcycle and ensure that all lights are working properly prior to riding.

# **Jardine**

**PERFORMANCE PRODUCTS**

## **Terms & Conditions**

**Returns:** All requests for product returns must be made within 30 days from date of purchase. The return has to have a Return Material Authorization (RMA) number from Jardine and must include a copy of the original purchase invoice. Customer pays for the return freight and Jardine will exchange product or process a credit to your account. All returns must be in the original packaging to be eligible for any credit or exchange. Any return sent C.O.D. will not be accepted. Special order sales are final and may not be returned.

**All warranty claims must be made through your point of purchase.**

**Limited Warranty:** Jardine's warranty extends to the original purchaser only and a copy of the sales receipt must be provided. Keep your receipts. Jardine products are warranted against defective materials and workmanship for a period of 1 year from date of original customer purchase and to the original customer only. Proof of purchase is required. Any non-defective, unopened, unused, not installed item may be returned within seven working days of receipt and will be subject to a 15% restocking / repackaging fee. Bluing and / or discoloration of chrome exhaust systems / products are not covered. Contact the Jardine Customer Service Department directly at 216-265-8400 to obtain a Return Material Authorization (RMA) number prior to return of product. Authorized product will be repaired or returned at Jardine's discretion. Jardine is not responsible for any other expenses, including labor for removal of defective parts incurred by the customer under the terms of this warranty. Nor shall Jardine be responsible for any damages whether consequential, special, contingent or otherwise, or expenses or injury arising from the use of Jardine products. A detailed copy of Sale Terms, Conditions and Warranty information is available at request.

Jardine and Jardine Performance Products are registered trademarks of SuperTrapp Industries, Inc. and may not be used without consent from SuperTrapp Industries, Inc. SuperTrapp Industries, Inc. retains all marketing rights to its products and trademarks.

Jardine Performance Products is manufactured by SuperTrapp Industries, Inc. in Cleveland, OH. Our exhausts, highway bars, backrests, fender kits & accessories for V-Twin, Metric, Sport & Dirt applications are made in the U.S.A. Jardine has been manufacturing performance products since 1959.

E: [Jardine@SuperTrapp.com](mailto:Jardine@SuperTrapp.com)

[www.JardineProducts.com](http://www.JardineProducts.com)

TECH: (216) 265-8400

REV: A 9-12-13