



Honda CBR600 F4i Slip On Hardware Kit



STOCK SYSTEM REMOVAL

- 1 Remove clamp from S-bend / head pipe joint.
- 2 Remove bolt holding the muffler to the foot peg.
- 3 Remove muffler.

KERKER® INSTALLATION

Complete the Kerker® Silencer Installation *before* following the steps below (refer to the Kerker® Silencer Installation Instruction Sheet included with the silencer).

- 1 Slide the T-bolt clamp over the slotted end of the S-bend and slide the S-bend onto the outlet end of the headpipe.
- 2 Install muffler, using hardware supplied. Install band clamp around muffler then mount to foot peg in this order: bolt, washer, clamp, second washer, spacer, third washer, foot peg mount, nut.
- 3 Align system and tighten all fasteners.

CUSTOMER SERVICE

Call Dealership or Point of Purchase in which the exhaust was purchased for questions on *returns, repairs, or fit and finish* of SuperTrapp® products.

Call SuperTrapp® Customer Service for *technical questions* between 8am-5pm Eastern Time, (216) 265-8400, or by fax, (216) 265-0130.

		Hardware Kit	Aluminum Muffler	Karbon Fiber Muffler	Mill Titanium Muffler	Rainbow Titanium Muffler	
Honda CBR600 F4i	Slip On's	Elliptical	114-30606	150-00018	170-00018	190-00018	195-00018

Since 1975, SuperTrapp® has built a reputation on innovation and technical superiority. SuperTrapp® R&D is constantly designing, testing and improving; providing you with the latest in state-of-the-art performance engineering. The Kerker® Performance Series is the culmination of hundreds of hours of street, track and dyno development. It will provide you with unmatched performance and lasting, trouble-free service.

