



PARTS INCLUDED

Ref.	Part Number	Description	Qty
1)	04-24-37907	Supersport Fender Bracket	1
2)	01-510610016-SS	Socket Button Head Bolt, M6-1.0x16mm	2
3)	01-510610020-SS	Socket Button Head Bolt, M6-1.0x20mm	2
4)	01-7006100-27	Nut, Hex Nylock, M6-1.0	2
5)	46-0001	License Plate Bolt Light Kit (Optional, Available Separately)	

REV. C
08-50-43887

46-1004-03

SUPERSPORT FENDER KIT

HONDA CBR600RR 2003-06
HONDA CBR1000RR 2004-07

TOOLS REQUIRED

Ref.	Description	Ref.	Description
1)	3/8" Drive Ratchet	5)	12mm Socket
2)	6" Extension	6)	10mm Wrench
3)	4mm Allen Socket	7)	Soldering Iron (optional)
4)	10mm Socket	8)	Wire Cutters (optional)

INSTALLATION INSTRUCTIONS

- 1) Remove the rider seat. Remove the passenger seat.
- 2) Disconnect the tail light. Remove and retain the tail section mounting bolts. Carefully remove the tail section from the motorcycle.
- 3) Disconnect the left & right turn signal wires at the connectors. Make note of the wire colors. Remove the turn signals from the license plate mount. Disconnect the license plate light wire.
- 4) Remove the four license plate mount mounting bolts. Remove the license plate mount from the motorcycle.
- 5) Install the Jardine supersport fender bracket to the original mounting location on the subframe. Mount the two front tabs by threading the supplied M6-1.0x20mm button head bolts from outside of the subframe and then through the supersport fender bracket. Secure using the two supplied M6-1.0 nylock nuts. Secure the two rear mounting tabs using the supplied M6-1.0x16mm button head bolts.
NOTE: The front hole of the supersport fender bracket should be placed to the inside of the front subframe mount. The rear hole should be placed to the outside.
- 6) Using the original hardware, mount the turn signals to the provided locations on the supersport fender bracket. Reconnect the turn signal wires.
- 7) Reinstall the tail section to the sub frame. Reinstall the rider and passenger seats.
- 8) Prior to riding the motorcycle, make sure the turn signals are working properly.

LICENSE PLATE BOLT LIGHT INSTALLATION (optional, available separately)

- 1) Use the license plate bolt lights to mount your license plate to the Supersport Fender Bracket.
- 2) Locate the now unused license plate light wires inside the tail section.

46-1004-03

SUPERSPORT FENDER KIT

HONDA CBR600RR 2003-06
HONDA CBR1000RR 2004-07

LICENSE PLATE BOLT LIGHT INSTALLATION (optional, available separately)

- 3) Cut and strip the two wires used to power the stock license plate light.
- 4) Attach both the red wires from the license plate light bolts to one of the stripped license plate light wires. Solder the connection and cover.
- 5) Attach both the black wires from the license plate light bolts to the second of the stripped license plate light wires. Solder the connection and cover.
- 6) Turn on the motorcycle and ensure that all lights are working properly prior to riding.

Jardine

PERFORMANCE PRODUCTS

Terms & Conditions

Returns: All requests for product returns must be made within 30 days from date of purchase. The return has to have a Return Material Authorization (RMA) number from Jardine and must include a copy of the original purchase invoice. Customer pays for the return freight and Jardine will exchange product or process a credit to your account. All returns must be in the original packaging to be eligible for any credit or exchange. Any return sent C.O.D. will not be accepted. Special order sales are final and may not be returned.

All warranty claims must be made through your point of purchase.

Limited Warranty: Jardine's warranty extends to the original purchaser only and a copy of the sales receipt must be provided. Keep your receipts. Jardine products are warranted against defective materials and workmanship for a period of 1 year from date of original customer purchase and to the original customer only. Proof of purchase is required. Any non-defective, unopened, unused, not installed item may be returned within seven working days of receipt and will be subject to a 15% restocking / repackaging fee. Bluing and / or discoloration of chrome exhaust systems / products are not covered. Contact the Jardine Customer Service Department directly at 216-265-8400 to obtain a Return Material Authorization (RMA) number prior to return of product. Authorized product will be repaired or returned at Jardine's discretion. Jardine is not responsible for any other expenses, including labor for removal of defective parts incurred by the customer under the terms of this warranty. Nor shall Jardine be responsible for any damages whether consequential, special, contingent or otherwise, or expenses or injury arising from the use of Jardine products. A detailed copy of Sale Terms, Conditions and Warranty information is available at request.

Jardine and Jardine Performance Products are registered trademarks of SuperTrapp Industries, Inc. and may not be used without consent from SuperTrapp Industries, Inc. SuperTrapp Industries, Inc. retains all marketing rights to its products and trademarks.

Jardine Performance Products is manufactured by SuperTrapp Industries, Inc. in Cleveland, OH. Our exhausts, highway bars, backrests, fender kits & accessories for V-Twin, Metric, Sport & Dirt applications are made in the U.S.A. Jardine has been manufacturing performance products since 1959.

E: Jardine@SuperTrapp.com

www.JardineProducts.com

TECH: (216) 265-8400

REV: A 9-12-13