

PARTS INCLUDED

Ref.	Part Number	Description	Qty
1)	04-24-46019	Supersport Fender Bracket	1
2)	01-44561016662	Nylon Spacer	4
	46-0001	License Plate Bolt Light Kit (Optional, Available Separately)	

REV. A
08-50-46020

46-4010-03

SUPERSPORT FENDER KIT



SUZUKI GSX-R1000
2009

TOOLS REQUIRED

Ref.	Description	Ref.	Description
1)	3/8" Drive Ratchet	5)	10mm Socket
2)	6" Extension	6)	12mm Socket
3)	5mm Allen Socket	7)	Soldering Iron (optional)
4)	8mm Socket	8)	Wire Cutters (optional)

INSTALLATION INSTRUCTIONS

- 1) Remove passenger seat (or rear cowl).
- 2) Remove indicated bolt from left and right side covers, below gas tank. Pull firmly to disengage and set aside. (Fig. 1)
- 3) Remove two bolts securing rider seat. Remove rider seat.
- 4) Remove indicated bolts, and push pin fasteners, from left side of motorcycle tail section (Fig. 2,3,4,5). Pull firmly to release left side tail section from rubber grommets.
- 5) Locate and disconnect the license plate light plug on the left side of the subframe and feed the wire through the hole in the rear fender.
- 6) Remove the stock rear fender by unbolting it from the tail section of the motorcycle, being careful to feed the license plate wire out through the hole in the tail section.
- 7) Thread the original bolts and washers through the mounting holes on the accessory license plate bracket. Place one supplied nylon washer onto each bolt and secure license plate bracket to underside of motorcycle. Tighten bolts to 13 N.m (9.5 lb-ft).
- 8) Using the original hardware and push pin fasteners, secure the left side of the tail section to the subframe.
- 9) Reinstall the rider seat and passenger seat (or rear cowl).





46-4010-03

SUPERSPORT FENDER KIT

SUZUKI GSX-R1000
2009

- 10) Reinstall the side covers to the motorcycle.
- 11) Turn on the motorcycle and check the operation of the license plate light and turn signals.
- 12) Mount your license plate to the new license plate bracket.



LICENSE PLATE BOLT LIGHT INSTALLATION (optional, available separately)

- 1) Use the license plate bolt lights to mount your license plate to the Supersport Fender Bracket.
- 2) Locate the now unused license plate light wires inside the tail section.
- 3) Cut and strip the two wires used to power the stock license plate light.
- 4) Attach both the red wires from the license plate light bolts to one of the stripped license plate light wires. Solder the connection and cover.
- 5) Attach both the black wires from the license plate light bolts to the second of the stripped license plate light wires. Solder the connection and cover.
- 6) Turn on the motorcycle and ensure that all lights are working properly prior to riding.

Jardine

PERFORMANCE PRODUCTS

Terms & Conditions

Returns: All requests for product returns must be made within 30 days from date of purchase. The return has to have a Return Material Authorization (RMA) number from Jardine and must include a copy of the original purchase invoice. Customer pays for the return freight and Jardine will exchange product or process a credit to your account. All returns must be in the original packaging to be eligible for any credit or exchange. Any return sent C.O.D. will not be accepted. Special order sales are final and may not be returned.

All warranty claims must be made through your point of purchase.

Limited Warranty: Jardine's warranty extends to the original purchaser only and a copy of the sales receipt must be provided. Keep your receipts. Jardine products are warranted against defective materials and workmanship for a period of 1 year from date of original customer purchase and to the original customer only. Proof of purchase is required. Any non-defective, unopened, unused, not installed item may be returned within seven working days of receipt and will be subject to a 15% restocking / repackaging fee. Bluing and / or discoloration of chrome exhaust systems / products are not covered. Contact the Jardine Customer Service Department directly at 216-265-8400 to obtain a Return Material Authorization (RMA) number prior to return of product. Authorized product will be repaired or returned at Jardine's discretion. Jardine is not responsible for any other expenses, including labor for removal of defective parts incurred by the customer under the terms of this warranty. Nor shall Jardine be responsible for any damages whether consequential, special, contingent or otherwise, or expenses or injury arising from the use of Jardine products. A detailed copy of Sale Terms, Conditions and Warranty information is available at request.

Jardine and Jardine Performance Products are registered trademarks of SuperTrapp Industries, Inc. and may not be used without consent from SuperTrapp Industries, Inc. SuperTrapp Industries, Inc. retains all marketing rights to its products and trademarks.

Jardine Performance Products is manufactured by SuperTrapp Industries, Inc. in Cleveland, OH. Our exhausts, highway bars, backrests, fender kits & accessories for V-Twin, Metric, Sport & Dirt applications are made in the U.S.A. Jardine has been manufacturing performance products since 1959.

E: Jardine@SuperTrapp.com

www.JardineProducts.com

TECH: (216) 265-8400

REV: A 9-12-13