



PARTS INCLUDED

Ref.	Part Number	Description	Qty
1)	04-24-42056	Supersport Fender Bracket	1
2)	04-18-35514	Mounting Spacer	4
3)	01-7306100-27	M6-1.0 Hex Flange Nut	4
	46-0001	License Plate Bolt Light Kit (Optional, Availabale Separately)	

08-50-42057 REV. B

46-2002-03

SUPERSPORT FENDER KIT

**YAMAHA YZF-R6
2006-07**

TOOLS REQUIRED

Ref.	Description	Ref.	Description
1)	3/8" Drive Ratchet	5)	12mm Socket
2)	6" Extension	6)	10mm Wrench
3)	4mm Allen Socket	7)	Soldering Iron (optional)
4)	10mm Socket	8)	Wire Cutters (optional)

INSTALLATION INSTRUCTIONS

- 1) Remove the passenger seat. Remove the tool kit and any other equipment you may have in the trunk area.
- 2) Disconnect the turn signal wires inside the trunk. Feed them out of the hole provided.
- 3) Remove the four bolts that secure the original turn signal mount to the motorcycle. Remove the turn signal mount.
- 4) Remove the left & right turn signals from the original mount. Install them onto the new Supersport Fender in the same fashion as stock.
- 5) Place the four spacers provided between the supersport fender and the tail section of the motorcycle. Secure the Supersport Fender to the tail section using the original bolts and the four provided M6-1.0 hex nylock nuts.
- 6) Feed the turn signal wires through the hole provided in the tail section. Reconnect the turn signal wires.
- 7) Turn on the motorcycle and make sure your turn signals are operating properly.
- 8) Place your tool kit and other equipment inside the trunk.
- 9) Reinstall the passenger seat.
- 10) Mount your license plate to the Supersport Fender.

LICENSE PLATE BOLT LIGHT INSTALLATION (optional, available separately)

- 1) Use the license plate bolt lights to mount your license plate to the Supersport Fender Bracket.
- 2) Locate the now unused license plate light wires inside the tail section.

46-2002-03

SUPERSPORT FENDER KIT

YAMAHA YZF-R1
2006-07

LICENSE PLATE BOLT LIGHT INSTALLATION (optional, available separately)

- 3) Cut and strip the two wires used to power the stock license plate light.
- 4) Attach both the red wires from the license plate light bolts to one of the stripped license plate light wires. Solder the connection and cover.
- 5) Attach both the black wires from the license plate light bolts to the second of the stripped license plate light wires. Solder the connection and cover.
- 6) Turn on the motorcycle and ensure that all lights are working properly prior to riding.



Terms & Conditions

Returns: All requests for product returns must be made within 30 days from date of purchase. The return has to have a Return Material Authorization (RMA) number from Jardine and must include a copy of the original purchase invoice. Customer pays for the return freight and Jardine will exchange product or process a credit to your account. All returns must be in the original packaging to be eligible for any credit or exchange. Any return sent C.O.D. will not be accepted. Special order sales are final and may not be returned.

All warranty claims must be made through your point of purchase.

Limited Warranty: Jardine's warranty extends to the original purchaser only and a copy of the sales receipt must be provided. Keep your receipts. Jardine products are warranted against defective materials and workmanship for a period of 1 year from date of original customer purchase and to the original customer only. Proof of purchase is required. Any non-defective, unopened, unused, not installed item may be returned within seven working days of receipt and will be subject to a 15% restocking / repackaging fee. Bluing and / or discoloration of chrome exhaust systems / products are not covered. Contact the Jardine Customer Service Department directly at 216-265-8400 to obtain a Return Material Authorization (RMA) number prior to return of product. Authorized product will be repaired or returned at Jardine's discretion. Jardine is not responsible for any other expenses, including labor for removal of defective parts incurred by the customer under the terms of this warranty. Nor shall Jardine be responsible for any damages whether consequential, special, contingent or otherwise, or expenses or injury arising from the use of Jardine products. A detailed copy of Sale Terms, Conditions and Warranty information is available at request.

Jardine and Jardine Performance Products are registered trademarks of SuperTrapp Industries, Inc. and may not be used without consent from SuperTrapp Industries, Inc. SuperTrapp Industries, Inc. retains all marketing rights to its products and trademarks.

Jardine Performance Products is manufactured by SuperTrapp Industries, Inc. in Cleveland, OH. Our exhausts, highway bars, backrests, fender kits & accessories for V-Twin, Metric, Sport & Dirt applications are made in the U.S.A. Jardine has been manufacturing performance products since 1959.

E: Jardine@SuperTrapp.com

www.JardineProducts.com

TECH: (216) 265-8400