

# Mean Mother™ Drag Pipes Louvred Baffles

**100-7460** Set of two optional louvred baffles to fit all Mean Mother Drag Pipes

## LOUVRED BAFFLE INSTALLATION

- 1 Remove pipes from bike if already installed.
- 2 Remove end cap from pipes by removing 2 Allen head screws and sliding out.
- 3 Slide baffle into pipe until it bottoms out and note location of end. Louvre openings should be facing you as you look into the pipe.
- 4 Tape outside of pipe where baffle ends with masking tape. This is to prevent scratching when drilling.
- 5 Drill 1/4" hole on backside approximately 2" from end of pipe through all three pipes.
- 6 Insert screw through hole and install locknut on inside of pipe.
- 7 Reinstall pipes and clean before restarting.

## CUSTOMER SERVICE

**Call Dealership or Point of Purchase** in which the exhaust was purchased for questions on *returns, repairs, or fit and finish* of SuperTrapp® products.

**Call SuperTrapp® Customer Service** for *technical questions* between 8am-5pm EST (216) 265-8400, or by fax, (216) 265-0130.

---

*Since 1975, SuperTrapp® has built a reputation on innovation and technical superiority. SuperTrapp® R&D is constantly designing, testing and improving; providing you with the latest in state-of-the-art performance engineering. The SuperTrapp® Mean Mothers™ Series products are absolutely the best bolt-on performance items available. They will provide years of trouble-free service.*

SuperTrapp® Industries, Inc.  
4540 W. 160th St. Cleveland, Ohio 44135 (216) 265-8400 fax. (216) 265-0130  
e-mail. [sales@supertrapp.com](mailto:sales@supertrapp.com) | [www.supertrapp.com](http://www.supertrapp.com)



003-7459 04.12.02

# Mean Mother™ Drag Pipes Louvred Baffles

**100-7460** Set of two optional louvred baffles to fit all Mean Mother Drag Pipes

## LOUVRED BAFFLE INSTALLATION

- 1 Remove pipes from bike if already installed.
- 2 Remove end cap from pipes by removing 2 Allen head screws and sliding out.
- 3 Slide baffle into pipe until it bottoms out and note location of end. Louvre openings should be facing you as you look into the pipe.
- 4 Tape outside of pipe where baffle ends with masking tape. This is to prevent scratching when drilling.
- 5 Drill 1/4" hole on backside approximately 2" from end of pipe through all three pipes.
- 6 Insert screw through hole and install locknut on inside of pipe.
- 7 Reinstall pipes and clean before restarting.

## CUSTOMER SERVICE

**Call Dealership or Point of Purchase** in which the exhaust was purchased for questions on *returns, repairs, or fit and finish* of SuperTrapp® products.

**Call SuperTrapp® Customer Service** for *technical questions* between 8am-5pm EST (216) 265-8400, or by fax, (216) 265-0130.

---

*Since 1975, SuperTrapp® has built a reputation on innovation and technical superiority. SuperTrapp® R&D is constantly designing, testing and improving; providing you with the latest in state-of-the-art performance engineering. The SuperTrapp® Mean Mothers™ Series products are absolutely the best bolt-on performance items available. They will provide years of trouble-free service.*

SuperTrapp® Industries, Inc.  
4540 W. 160th St. Cleveland, Ohio 44135 (216) 265-8400 fax. (216) 265-0130  
e-mail. [sales@supertrapp.com](mailto:sales@supertrapp.com) | [www.supertrapp.com](http://www.supertrapp.com)



003-7459 04.12.02