



PARTS INCLUDED

Ref.	Part Number	Description	Qty
1)	00-200-02392	Slip-on Midpipe Assembly	1
2)	00-200-02396	RT5 Muffler, Carbon Fiber	1
3)	00-200-02398	Midpipe Heat Shield	1
4)	03-46-47231	Muffler Adapter Bracket	1
5)	01-510812525-SS	M8-1.25x25mm Socket Button Head Bolt	1
6)	01-7408125-27	M8-1.25 Hex Flange Nut	2
7)	07-38-42068-35	T-Bolt Clamp	1
8)	07-38-32HC	#32 Hose Clamp	1

08-50-47241 REV. A

19-8003-323-02

RT5 SLIP-ON EXHAUST, SS/CARBON

BMW S1000RR
2010-11

TOOLS REQUIRED

Ref.	Description
1)	3/8" Drive Ratchet
2)	3" Extension
3)	8mm Socket
4)	10mm Socket
5)	12mm Socket
6)	Phillips Screwdriver
7)	5mm Allen Socket
8)	8mm Allen Socket
9)	8mm Wrench
10)	11mm Wrench
11)	Torque Wrench
12)	Spring Tool or Needlenose Pliers

INSTALLATION INSTRUCTIONS

NOTE: Make sure the motorcycle is cool and secure on a service lift or stand before attempting any installation.

- 1) Loosen the stock muffler inlet clamp bolt. (Fig. 1)
- 2) Remove the bolt that secures the stock resonator to the right side rider footpeg. (Fig. 1) Remove the stock resonator.
- 3) Remove the stock heat shield form the under-body muffler outlet.
- 4) Loosely place the provided t-bolt clamp over the notched inlet of the Jardine slip-on midpipe. Slide the midpipe onto the under-body muffler outlet tube. (Fig. 2) Do not tighten clamp at this time.
- 5) Using the original resonator mounting bolt, and one supplied M8-1.25 hex flange nut, loosely secure the muffler adapter bracket to the rider footpeg mount, as shown. (Fig. 3)
- 6) Slide the Jardine muffler onto the midpipe outlet. Position the midpipe and muffler, and secure to the muffler adapter bracket using the supplied M8-1.25x25mm button head bolt, and M8-1.25 hex flange nut. Do not fully tighten at this time. (Fig. 3)



Fig. 1



Fig. 2

19-8003-323-02

RT5 SLIP-ON EXHAUST, SS/CARBON

BMW S1000RR
2010-11

INSTALLATION INSTRUCTIONS

- 7) Thread the supplied hose clamp into the bracket provided on the back of the new midpipe heat shield. Slide the tab on the new heat shield into the mount on the under-body muffler outlet.
- 8) Position the complete slip-on exhaust in the best possible orientation. Fully tighten the midpipe t-bolt clamp, then the muffler adapter bracket and muffler mounting bolts. Lastly, fully tighten the hose clamp securing the midpipe heat shield. (Fig. 4)
NOTE: Make sure that the t-bolt clamp is covering the notches on the midpipe inlet.
- 9) Clean any fingerprints and grease from the muffler and heat shield.
- 10) Start the motorcycle, look and sound better than you did before you started Step 1.



Fig. 3



Fig. 4

Jardine

PERFORMANCE PRODUCTS

Terms & Conditions

Returns: All requests for product returns must be made within 30 days from date of purchase. The return has to have a Return Material Authorization (RMA) number from Jardine and must include a copy of the original purchase invoice. Customer pays for the return freight and Jardine will exchange product or process a credit to your account. All returns must be in the original packaging to be eligible for any credit or exchange. Any return sent C.O.D. will not be accepted. Special order sales are final and may not be returned.

All warranty claims must be made through your point of purchase.

Limited Warranty: Jardine's warranty extends to the original purchaser only and a copy of the sales receipt must be provided. Keep your receipts. Jardine products are warranted against defective materials and workmanship for a period of 1 year from date of original customer purchase and to the original customer only. Proof of purchase is required. Any non-defective, unopened, unused, not installed item may be returned within seven working days of receipt and will be subject to a 15% restocking / repackaging fee. Bluing and / or discoloration of chrome exhaust systems / products are not covered. Contact the Jardine Customer Service Department directly at 216-265-8400 to obtain a Return Material Authorization (RMA) number prior to return of product. Authorized product will be repaired or returned at Jardine's discretion. Jardine is not responsible for any other expenses, including labor for removal of defective parts incurred by the customer under the terms of this warranty. Nor shall Jardine be responsible for any damages whether consequential, special, contingent or otherwise, or expenses or injury arising from the use of Jardine products. A detailed copy of Sale Terms, Conditions and Warranty information is available at request.

Jardine and Jardine Performance Products are registered trademarks of SuperTrapp Industries, Inc. and may not be used without consent from SuperTrapp Industries, Inc. SuperTrapp Industries, Inc. retains all marketing rights to its products and trademarks.

Jardine Performance Products is manufactured by SuperTrapp Industries, Inc. in Cleveland, OH. Our exhausts, highway bars, backrests, fender kits & accessories for V-Twin, Metric, Sport & Dirt applications are made in the U.S.A. Jardine has been manufacturing performance products since 1959.

E: Jardine@SuperTrapp.com

www.JardineProducts.com

TECH: (216) 265-8400

REV: A 9-12-13