



**PARTS INCLUDED**

Ref.	Part Number	Description	Qty
1)	04-24-47327	Supersport Fender Bracket	1
2)	02-03-47328	Mounting Spacer, Short	2
3)	02-03-47329	Mounting Spacer, Tall	1
	46-0001	License Plate Bolt Light Kit (Optional, Available Separately)	

08-50-47330 REV. A

46-8001-03

## SUPERSPORT FENDER KIT

BMW S1000RR  
2010-2011

### TOOLS REQUIRED

Ref.	Description	Ref.	Description
1)	3/8" Drive Ratchet	5)	12mm Socket
2)	6" Extension	6)	10mm Wrench
3)	5mm Allen Socket	7)	Soldering Iron (optional)
4)	10mm Socket	8)	Wire Cutters (optional)

### INSTALLATION INSTRUCTIONS

**NOTE: BEFORE DOING ANY WORK, MAKE SURE THE MOTORCYCLE IS COOL, AND IT IS SECURE ON A SERVICE LIFT OR THE KICK STAND.**

- 1) Remove the passenger seat or cowl. Remove the license plate from the stock rear fender.
- 2) Disconnect the license plate light wire and the two turn signal wires, inside the trunk space. Feed the wires through the hole in the tail section.
- 3) Remove the three bolts that secure the rear fender to the tail section. Remove the stock rear fender.
- 4) Remove the left and right turn signals from the stock rear fender. Make note of the connector color for the right & left turn signal wires.
- 5) Install the turn signals to the new Supersport Fender bracket.
- 6) Place the supplied Tall Mounting Spacer between the Supersport Fender bracket and the center mount on the motorcycle tail section. Place the two supplied Short Mounting Spacers between the Supersport Fender bracket and the front/side mounts on the motorcycle tail section.



Fig. 1



Fig. 2

46-8001-03

**SUPERSPORT FENDER KIT**

**BMW S1000RR  
2010-2011**

- 7) Using the original bolts, secure the Supersport Fender Bracket, and mounting spacers, to the tail section of the motorcycle. Tighten the mounting hardware to factory specification.
- 8) Feed the turn signal wires through the hole in the tail section and reconnect them to the wiring in the truck area.
- 9) Turn on the motorcycle and make sure all lighting is working correctly.
- 10) Reinstall the passenger seat.



**LICENSE PLATE BOLT LIGHT INSTALLATION (optional, available separately)**

- 1) Use the license plate bolt lights to mount your license plate to the Supersport Fender Bracket.
- 2) Locate the now unused license plate light wires inside the tail section.
- 3) Cut and strip the two wires used to power the stock license plate light.
- 4) Attach both the red wires from the license plate light bolts to one of the stripped license plate light wires. Solder the connection and cover.
- 5) Attach both the black wires from the license plate light bolts to the second of the stripped license plate light wires. Solder the connection and cover.
- 6) Turn on the motorcycle and ensure that all lights are working properly prior to riding.



## Terms & Conditions

**Returns:** All requests for product returns must be made within 30 days from date of purchase. The return has to have a Return Material Authorization (RMA) number from Jardine and must include a copy of the original purchase invoice. Customer pays for the return freight and Jardine will exchange product or process a credit to your account. All returns must be in the original packaging to be eligible for any credit or exchange. Any return sent C.O.D. will not be accepted. Special order sales are final and may not be returned.

**All warranty claims must be made through your point of purchase.**

**Limited Warranty:** Jardine's warranty extends to the original purchaser only and a copy of the sales receipt must be provided. Keep your receipts. Jardine products are warranted against defective materials and workmanship for a period of 1 year from date of original customer purchase and to the original customer only. Proof of purchase is required. Any non-defective, unopened, unused, not installed item may be returned within seven working days of receipt and will be subject to a 15% restocking / repackaging fee. Bluing and / or discoloration of chrome exhaust systems / products are not covered. Contact the Jardine Customer Service Department directly at 216-265-8400 to obtain a Return Material Authorization (RMA) number prior to return of product. Authorized product will be repaired or returned at Jardine's discretion. Jardine is not responsible for any other expenses, including labor for removal of defective parts incurred by the customer under the terms of this warranty. Nor shall Jardine be responsible for any damages whether consequential, special, contingent or otherwise, or expenses or injury arising from the use of Jardine products. A detailed copy of Sale Terms, Conditions and Warranty information is available at request.

Jardine and Jardine Performance Products are registered trademarks of SuperTrapp Industries, Inc. and may not be used without consent from SuperTrapp Industries, Inc. SuperTrapp Industries, Inc. retains all marketing rights to its products and trademarks.

Jardine Performance Products is manufactured by SuperTrapp Industries, Inc. in Cleveland, OH. Our exhausts, highway bars, backrests, fender kits & accessories for V-Twin, Metric, Sport & Dirt applications are made in the U.S.A. Jardine has been manufacturing performance products since 1959.

E: [Jardine@SuperTrapp.com](mailto:Jardine@SuperTrapp.com)

[www.JardineProducts.com](http://www.JardineProducts.com)

TECH: (216) 265-8400